


# User Guide

## COMMANDER 100 Universal Process Controller



# Use of Instructions



## **Warning.**

An instruction that draws attention to the risk of injury or death.



## **Caution.**

An instruction that draws attention to the risk of damage to the product, process or surroundings.



## **Note.**

Clarification of an instruction or additional information.



## **Information.**

Further reference for more detailed information or technical details.

Although **Warning** hazards are related to personal injury, and **Caution** hazards are associated with equipment or property damage, it must be understood that operation of damaged equipment could, under certain operational conditions, result in degraded process system performance leading to personal injury or death. Therefore, comply fully with all **Warning** and **Caution** notices.

Information in this manual is intended only to assist our customers in the efficient operation of our equipment. Use of this manual for any other purpose is specifically prohibited and its contents are not to be reproduced in full or part without prior approval of Technical Communications Department, ABB Instrumentation.

## **Health and Safety**

To ensure that our products are safe and without risk to health, the following points must be noted:

1. The relevant sections of these instructions must be read carefully before proceeding.
2. Warning labels on containers and packages must be observed.
3. Installation, operation, maintenance and servicing must only be carried out by suitably trained personnel and in accordance with the information given.
4. Normal safety precautions must be taken to avoid the possibility of an accident occurring when operating in conditions of high pressure and/or temperature.
5. Chemicals must be stored away from heat, protected from temperature extremes and powders kept dry. Normal safe handling procedures must be used.
6. When disposing of chemicals ensure that no two chemicals are mixed.


Safety advice concerning the use of the equipment described in this manual or any relevant hazard data sheets (where applicable) may be obtained from the Company address on the back cover, together with servicing and spares information.

---

# GETTING STARTED


---

This manual is divided into 5 sections which contain all the information needed to install, configure, commission and operate the COMMANDER 100. Each section is identified clearly by a symbol as shown below.




## Displays and Function Keys

- Displays and function keys
- LED Indication
- Error Messages




## Operator Mode (Level 1)

- Operator menus for:
  - *Standard controller*
  - *Heat/Cool controller*
  - *Remote Set Point controller*
  - *Profile controller*
  - *Multiple Fixed Set Points controller*
- Auto tuning



## Set Up Mode (Levels 2, 3 and 4)

- Level 2 – Tuning
- Level 3 – Set Points
- Level 4 – Profile



## Configuration Mode (Levels 5 and 6)

- Level 5 – Basic hardware and control functions
- Level 6 – Ranges and passwords



## Installation

- Siting
- Mounting
- Electrical connections

## Symbol Identification and Section Contents


# CONTENTS

<b>1</b>	<b>DISPLAYS AND FUNCTION KEYS .....</b>	<b>3</b>
1.1	Introduction .....	3
1.2	Use of Function Keys .....	4
1.3	LED Alarms and Indicators .....	5
1.4	Error Messages .....	6
<b>2</b>	<b>OPERATOR MODE .....</b>	<b>7</b>
2.1	Introduction .....	7
2.2	Standard Controller .....	8
2.3	Heat/Cool Controller .....	9
2.4	Remote Set Point Controller .....	10
2.5	Profile Controller .....	12
2.6	Multiple Fixed Set Points Controller .....	14
2.7	Auto-tune .....	16
<b>3</b>	<b>SET UP MODE .....</b>	<b>18</b>
3.1	Introduction .....	18
3.2	Tuning (Level 2) .....	18
3.3	Set Points (Level 3) .....	22
3.4	Profile (Level 4) .....	25
<b>4</b>	<b>CONFIGURATION MODE .....</b>	<b>28</b>
4.1	Introduction .....	
4.2	Accessing the Configuration Mode .....	28
4.3	Basic Hardware and Configuration (Level 5) .....	30
4.4	Ranges and Passwords (Level 6) .....	40
<b>5</b>	<b>INSTALLATION .....</b>	<b>43</b>
5.1	Siting .....	43
5.2	Mounting .....	45
5.3	Electrical Connections .....	47
5.4	Relays, Arc Suppression, Digital Input and Output .....	47



## Information.


The fold-out page inside on the back cover of this manual shows all the frames in the programming levels. Space is provided on the page for writing the programmed setting or selection for each frame.



# 1 DISPLAYS AND FUNCTION KEYS

## 1.1 Introduction – Fig. 1.1


The COMMANDER 100 front panel displays, function keys and LED indicators are shown in Fig. 1.1.




**Fig. 1.1 Front Panel Displays, Function Keys and Indicators**

## 1.2 Use of Function Keys – Fig. 1.2

### A – Raise and Lower Keys




### B – Parameter Advance Key




**Note.** This key also stores any changes made in the previous frame

### C – Auto/Manual Key



**Fig. 1.2 Use of Function Keys**










## 1.3 LED Alarms and Indicators

**LED      Status**

- All**      • All LED's flashing – controller is in the configuration mode.
- A1**      • Flashes when Alarm 1 is active (off when inactive).
- A2**      • Flashes when Alarm 2 is active (off when inactive).
- R**      • On when the controller is operating on the remote set point value.  
          • Off when the controller is operating using the local set point value or one of the four fixed set points (in multiple set point mode).  
          • Flashes when a Ramp/Soak profile is running.
- M**      • On when the controller is operating in Manual control mode.  
          • Off when the controller is operating in Auto control mode.  
          • Flashes when the controller is performing an auto-tune.
- OPI**      • Secret-til-lit LED indicates when the output 1 (heat) value is displayed in the lower display.
- OP2**      • Secret-til-lit LED indicates when the output 2 (cool) value is displayed in the lower display.

**Fig. 1.3 LED Alarms and Indicators**

## 1.4 Error Messages

Display	Error/Action	To Clear Display
	<b>Calibration error</b> Turn mains power off and on again (if the error persists contact the Service Organization).	Press the  key
	<b>Configuration error</b> The configuration and/or setup data for the instrument is corrupted. Turn mains power off and on again (if the error persists, check configuration/setup settings).	Press the  key
	<b>A to D Converter Fault</b> The analog to digital converter is not communicating correctly.	Turn power off and on again, if the problem persists contact the service organization
	<b>Process Variable Over/Under Range</b>	Restore valid input
	<b>Remote Set Point Over/Under Range</b> The remote set point value is over or under range. Flashing stops automatically when the remote set point input comes back into range.	Select the local set point ( <i>r SP.n</i> ) in the Operating Page or the Set Points Level
	<b>Option error</b> Communications to the option board have failed.	Contact the Service Organization
	<b>Auto-tune error</b> The number displayed indicates the type of error present – see Table 2.1 in Section 2.7.	Press any key





---

## 2 OPERATOR MODE

---

### 2.1 Introduction

Operator Mode (Level 1) is the normal day-to-day mode of the COMMANDER 100.

Frames displayed in level 1 are determined by the control strategy which is selected during configuration of the instrument – see Section 4.



**Note.** Only the operating frames relevant to the configured strategy are displayed in Operator Mode.


The five control strategies are:

- **Standard controller** – page 8
- **Heat/Cool controller** – page 9
- **Remote Set Point controller** – page 10
- **Profile controller** – page 12
- **Multiple Fixed Set Points controller** – page 14



## ...2 OPERATOR MODE


### 2.2 Standard Controller



- 1 Not displayed if the ramping set point facility is turned off – refer to Section 3.3.




## 2.3 Heat/Cool Controller




- 1 Not displayed if the ramping set point facility is turned off – refer to Section 3.3.



### 2.4 Remote Set Point Controller




#### Note.

If the remote set point input fails while selected, the controller automatically selects the local set point value. The upper display changes to *rSP.F* and the lower display flashes. When the fault condition is removed the remote set point is re-selected automatically. To clear the error condition while the remote set point input is still outside its allowed range, select the local set point by pressing the  key (*rSP.n* is displayed).



### ...2.4 Remote Set Point Controller




- 1 Not displayed if the ramping set point facility is turned off – refer to Section 3.3.





## ...2.5 Profile Controller




- 1 Not displayed if the ramping set point facility is turned off – refer to Section 3.3.



## ...2 OPERATOR MODE

### 2.6 Multiple Fixed Set Points Controller

If the Multiple Fixed Set Points Controller type is selected during configuration, four fixed control set points can be set – see Section 4.4.




- 1 Not displayed if the ramping set point facility is turned off – refer to Section 3.3.





## ...2.6 Multiple Fixed Set Points Controller






### 2.7 Auto-tune

#### **i** Information.


- Auto-tune optimizes process control by monitoring process performance and automatically updates the control parameters.
- Before starting auto-tune, the process variable must be stable ( $\pm 2\%$  of engineering range).

#### 1 – 'At start up' auto-tune (from manual mode)




1a – Stable process before auto-tune


#### 2 – 'At set point' auto-tune (from manual or automatic mode)



2a – Stable process before auto-tune




1b – Process response during auto-tune



2b – Process response during auto-tune

**★ Note.** The time taken to complete autotune depends upon the system response time.




Process response after auto-tune

**Fig 2.1 Typical Auto-tune Cycles**



### ...2.7 Auto-tune



#### Notes.


- On completion the controller enters auto control mode and begins to control the process using the new PID values. For fine-tuning – see Section 3.
- For heat/cool control the cool proportional band is set to the same value as the heat proportional band (this value may need modification).
- If an error occurs during auto-tune, the controller reverts to manual mode with the control output set to the configured output value. An error message is displayed – see Table 2.1.

Error	Description	Error	Description
1	PV failed during auto-tune	7	A resultant P, I or D value was calculated out of range
2	Auto-tune has timed out during an auto-tune step	8	PV limit exceeded (At start up auto-tune)
3	Process too noisy to auto-tune	9	Controller put into configuration mode
4	Process too fast to auto-tune	10	Auto-tune terminated by user
5	Process too slow to auto-tune	11	PV is changing in the wrong direction during step test
6	PV deviated from set point by >25% eng. span during frequency response test		


**Table 2.1 Auto-tune Error Codes**

## 3.1 Introduction


To access the Set Up Mode (Levels 2, 3 and 4) the correct password must be entered in the security code frame (the default password code is 0). Refer to the fold-out sheet at the back of this manual for the contents of these levels.




Refer to the fold-out sheet for the contents of each level




## 3.2 Tuning (Level 2) – Fig. 3.2




- 1 Only displayed if output 1 is assigned to a relay or logic output.
- 2 Only displayed if heat/cool hardware configuration is selected.



### ...3.2 Tuning (Level 2) – Fig. 3.2




- 1 Only displayed if On/Off control is selected for either output.
- 2 Only displayed if heat/cool hardware configuration is selected.




## ...3 SET UP MODE


### ...3.2 Tuning (Level 2)




- 1 Only displayed if a heat/cool hardware configuration is selected.



**Fig. 3.1 Proportional Band & Deadband/Overlap – Heat/Cool Control Only**




### 3.3 Set Points (Level 3)




•1 Only displayed if the remote set point option is selected.





### ...3.3 Set Points (Level 3)




- 1 Only displayed if custom alarm hysteresis is selected – see section 4.3.2, not displayed if Loop Break Alarm type selected.
- 2 Only displayed if the remote set point option is selected.



## ...3 SET UP MODE

### ...3.3 Set Points Level




#### Ramp Rate (for ramping set point facility)


[1 to 9999 engineering units per hour, or OFF]

The ramping set point facility can be used to prevent a large disturbance to the control output when the set point value is changed. This only applies to the local and multiple fixed set points.

**\* Note.** For remote set points the ramp rate is applicable when switching from remote to local, not local to remote




\* e.g. Ramp Rate = 200 Increments/Hour



#### Offset Adjustment


An offset can be applied to the process variable input to enable spot calibration or the removal of system errors.

[±10% of engineering range in engineering units]



### 3.4 Profile (Level 4)

A four segment ramp/soak profile facility is provided. This level can only be accessed if the profile option is selected in the configuration level. The four segments are fixed as ramps or soaks as follows:



LEU.4  
PrFL



•1 Str.1  
100.0



End.1  
200.0



rtE.1  
10.0

#### Level 4 – Profile Level



**Note.** To select to this frame from anywhere in this page, press the key for a few seconds.

#### Start value for 1<sup>st</sup> Segment (ramp).

[Within display range (in engineering units)]

Enter the start value required.

#### End Value for 1<sup>st</sup> Segment (ramp).

[Within display range (in engineering units)]

Enter the end value required.

Continued on next page.

- 1 With the self-seeking set point facility enabled, the first ramp starts at the current process variable value instead of the start value for the 1<sup>st</sup> segment.



## ...3 SET UP MODE

### ...3.4 Profile (Level 4)

•1

**Ramp Rate for 1<sup>st</sup> Segment.**  
[Engineering units\* ]

Enter the ramp rate required.  
\* The time option Eng Units/hr or Eng Units/min is set in the configuration level – see section 4.3.2.

Example. Required Ramp Rate 40°C/min  
Ramp Rate set to 40, Time Option set to 'Min' – see section 4.3.2

**Soak Time for 2<sup>nd</sup> Segment.**  
[0 to 999.9 minutes or hours]\*


**End Value for 3<sup>rd</sup> Segment (ramp).**  
[Within display range (in engineering units)]

**Ramp Rate for 3<sup>rd</sup> Segment.**  
[Engineering units/hour or /minute]\*


\* Depending on the time option selected in the configuration level.

Continued on next page.

- 1 The engineering value is shown with an extra decimal place (up to a maximum of 3) for greater accuracy in setting the ramp rate.



### ...3.4 Profile (Level 4)



- 2 The engineering value is shown with an extra decimal place (up to a maximum of 3) for greater accuracy in setting the ramp rate.



## 4 CONFIGURATION MODE

### 4.1 Introduction

The Configuration Mode comprises two levels (5 and 6) as shown in Fig. 4.2.

Level 5 is divided into four frames. For most simple applications it is only necessary to set up the parameters in the first frame.




#### Note.

When in the configuration level:

- All the l.e.d. indicators flash.
- All relays and logic outputs are turned off.
- The analog output reverts to 0% (4mA) output level.

### 4.2 Accessing the Configuration Mode – Fig. 4.1

To access the Configuration Mode set the security switch to the 'Configure' position (levels 1 to 4 cannot be accessed from this setting). When the configuration parameters are programmed, reset the security switch to the 'Normal' position and the Operating page is displayed automatically .



**Fig. 4.1 Accessing the Configuration Mode (Config/Normal Switch)**





Fig. 4.2 Configuration Frames (Levels 5 and 6)



## ...4 CONFIGURATION MODE

### 4.3 Basic Hardware and Configuration (Level 5)

#### 4.3.1 Hardware Assignment and Input Type – Fig. 4.3

LEU.5  
CnFG



AbCd  
24 10



EFGH  
---

#### Level 5 –Configuration



**Note.** To select this frame from anywhere in this page, press the  key for a few seconds.

#### 'ABCD' Settings

AbCd  
24 10



AbCd  
24 10



AbCd  
24 10



The parameter to be changed is indicated by the letter which is flashing. Parameter options are shown in Fig. 4.3.

- A* = Hardware configuration
- b* = Input type and range
- C* = Temperature units
- d* = Process variable display decimal places




**Note 1.** The temperature ranges default to their maximum values when the input type is changed.



**Note 2.** For custom settings contact the local distributor.

Continued on page 32.





AbCd  
24C0

## A – Hardware Configuration

Freq.	Relay 1	Relay 2*	Relay 3*	Logic O/P	An. O/P	Control Type
50Hz 60Hz						
1 A	Output 1	Alarm 1	Alarm 2	Output 1	PV	Time Prop. or On/Off
2 b	Alarm 1	Alarm 2	None	None	Output 1	Analog Prop.
3 c	Output 1	Output 2	Alarm 1	Output 1	PV	Heat – Time Prop. Cool – Time Prop.
4 d	Output 2	Alarm 1	Alarm 2	Output 2	Output 1	Heat – Analog Cool – TP or On/Off
5 E	Alarm 1	Alarm 2	None	Output 1	PV	Alarm Unit or Logic O/P Time Prop.
U	Custom	Custom	Custom	Custom	Custom	Custom

\* Only available if option board is fitted

AbCd  
24C0

## B – Input Type and Range Configuration

Display		Display	
b	THC Type B	1	0 to 20 mA
E	THC Type E	2	4 to 20 mA
J	THC Type J	3	0 to 5 V
K	THC Type K	4	1 to 5 V
N	THC Type N	6	0 to 50 mV
R	THC Type R	7	4 to 20 mA (square root lineariser)
S	THC Type S	U	Custom Configuration
T	THC Type T		
P	PT100 RTD		

AbCd  
24C0

## C – Temperature Units

Display	Temperature Units
C	Degrees C*
F	Degrees F*
0	No temperature units

AbCd  
24C0

## D – Process Variable Display Decimal Places

Display	
0	xxxx
1	xxx . x
2	xx . xx
3	x . xxx

\* Temperature inputs only

**Fig. 4.3 Hardware Assignment and Input Type**




## ...4 CONFIGURATION MODE

### 4.3.2 Alarms and Set Point Types – Fig. 4.4



**Note.** All relays are de-energised in the alarm state.





EFGH  
3241

## E – Alarm 1 Type\*

Display	
0	None
1	High Process
2	Low Process
3	High Deviation
4	Low Deviation
5	Loop Break

EFGH  
3241

## F – Alarm 2 Type\*

Display	
0	None
1	High Process
2	Low Process
3	High Deviation
4	Low Deviation
5	Loop Break

\* Refer to Figs. 4.5 and 4.6 for alarm action

EFGH  
3241

## G – Alarm Hysteresis

Display	
0	None
1	0.1%
2	0.2%
3	0.5%
4	1.0%
5	2.0%
6	5.0%
U	Custom

Value in % of  
engineering  
range

Value in engineering units \*



**Note 1.** When custom alarm hysteresis is selected, the alarm hysteresis values are set individually in the set up level – see section 3.3

EFGH  
3241

## H – Set Point Type

Display	
0	Local Set Point Only
1	Local + Remote Set Point (no Remote Set Point Tracking)**
2	Local + Remote Set Point (with Remote Set Point Tracking)**
3	Multiple Fixed Set Points
4	Ramp/Soak (Time Units in Minutes)
5	Ramp/Soak (Time Units in Hours)

\*

\*\*Only available if option board is fitted. Remote set point input is 4 to 20 mA



**Note 2.** With remote set point tracking enabled the local set point tracks the remote set point when in the remote set point mode.

**Fig. 4.4 Alarms and Set Point Types**



## ...4 CONFIGURATION MODE

### ...4.3.2 Alarms and Set Point Types – Fig. 4.4





**Note.** All relays are de-energised in the alarm state.

#### Loop Break Alarm


The loop break alarm indicates a fault in the control loop (e.g. failure of a heating element in a furnace). If the control output remains at maximum or minimum for a time exceeding the trip value (in seconds) without any response in the process value, the loop break alarm is activated.

#### Process and Deviation Alarms (High/Low) – Figs 4.5 and 4.6





High Deviation Alarm



Low Deviation Alarm

Fig. 4.6 High and Low Deviation Alarm Action




---

## ...4 CONFIGURATION MODE

---

### 4.3.3 Operator Access and Control Action – Fig. 4.7





JPLn  
23 10

## J – Power Recovery Mode

Display	Mode
0	Last Mode
1	Manual with Last Output
2	Manual with 0.0% Output
3	Manual with 100.0% Output
4	Auto
U	Custom

JPLn  
23 10

## K – Operator Selection Enable Control Functions

Display	Auto/Manual and Autotune
0	Enable Both Functions
1	Disable A/M, Enable Auto-tune
2	Enable A/M, Disable Auto-tune
3	Disable Both Functions

JPLn  
23 10

## L – Operator Selection Enable – Set Point Functions

Display	Local Set Point Adjustment and Local/Remote Set Point Selection
0	Enable Both Functions
1	Disable Set Point Adjust, Enable Local/Remote Selection
2	Enable Set Point Adjust, Disable Local Remote Function
3	Disable Both Functions

JPLn  
23 10


## N – Control Action

Display	Heat Action	Cool Action
0	Reverse	Direct
1	Direct	Reverse

**Fig. 4.7 Operator Access and Control Action**



### 4.3.4 Digital Input and Serial Communications – Fig. 4.8




The parameter to be changed is indicated by the letter which is flashing. Parameter options are shown in Fig. 4.8.


- P = Digital input function
- r = Analog input digital filter
- S = Serial communications configuration
- t = Serial communication parity



**Note.** For custom settings contact the local distributor.







P-5t  
2 100

#### P – Digital Input Functions

Display	Function
0	None
1	Auto/Manual
2	Local/Remote
3	Auto-tune Start
4	Ramp/Soak Run-Hold
5	Ramp/Soak Run-Stop
6	Front Panel Lockout
7	Select Fixed Set Points

P-5t  
2 100

#### R – Analog Input Digital Filter

Display	
0	0 seconds
1	1 second
2	2 seconds
5	5 seconds
A	10 seconds
B	20 seconds
C	40 seconds
D	60 seconds

Input filter averages the process variable input values over the time set

P-5t  
2 100

#### S – Serial Communication Configuration

Display	Baud Rate, 2/4 Wire
0	Off
1	2400, 2 Wire
2	2400, 4 Wire
3	9600, 2 Wire
4	9600, 4 Wire

P-5t  
2 100

#### T – Serial Communications Parity


Display	
0	None
1	Odd
2	Even

Fig. 4.9 Digital Input and Serial Communications




## ...4 CONFIGURATION MODE


### 4.4 Ranges and Passwords (Level 6)



- 1 The engineering range high and low values are automatically set to the maximum allowed value when thermocouple or RTD is selected in the configuration level – see Section 4.3.1. This value can be modified if required.
- 2 Only displayed if the analog output is configured to retransmit the process variable or control set point value.



#### ...4.4 Ranges and Passwords (Level 6)




- 1 This limit applies to the local and remote set point values.
- 2 Only displayed if the multiple fixed set point facility is selected.



## ...4 CONFIGURATION MODE

### ...4.4 Ranges and Passwords (Level 6)




This frame allows the Modbus address to be set.

- 1 This value only applies in automatic mode.  
The low limit is automatically set to 0.0% (–10% for analog outputs).
- 2 Only displayed if a heat/cool hardware configuration is selected.



## 5 INSTALLATION



### 5.1 Siting – Figs. 5.1 and 5.2






## ...5 INSTALLATION

### ...5.1 Siting – Figs. 5.1 and 5.2





**Temperature Limits**

**Humidity Limits**



0 to 90% RH





**IP65/NEMA3**  
(front panel)

**IP20**  
(rear)

**Environmental Limits**

**Use Screened Cable**




**Fig. 5.2 Environmental Requirements**



## 5.2 Mounting – Figs. 5.3 and 5.4

The instrument is designed for panel mounting (see Fig. 5.4). Overall dimensions are shown in Fig. 5.3.




**Fig. 5.3 Overall Dimensions**



## ...5 INSTALLATION

### ...5.2 Mounting – Figs. 5.3 and 5.4







## EC Directive 89/336/EEC

In order to meet the requirements of the EC Directive 89/336/EEC for EMC regulations, this product must not be used in a non-industrial environment.

## 5.3 Electrical Connections – Fig. 5.5 (overleaf)



**Warning.** Before making any connections, ensure that the power supply, any powered control circuits and high common mode voltages are switched off. The instrument must be connected in accordance with local regulations and have an external means of disconnection. External fuse rating must not exceed 5A.



**Note.** If it is not possible to avoid strong electrical and magnetic fields, screened cables within earthed metal conduit must be used.

## 5.4 Relays, Arc Suppression and Outputs

### 5.4.1 Relay Contact Ratings

Relay contacts are rated at:

115/230V AC at 5A (non-inductive).

250V DC 25W max.

### 5.4.2 Arc Suppression

Arc suppression components are fitted to relays 2 and 3 only. If relay 1 is required to switch inductive loads, fit the arc suppression components supplied.

### 5.4.3 Logic Output

18V DC at 20mA.

Min load 900Ω.

Isolation from Analog Output (not isolated from Retransmission Output). Dielectric strength – 500V d.c. for 1 minute.

### 5.4.4 Control or Retransmission Analog Outputs

Max. load 15V (750Ω at 20mA).

Isolation from Analog Output (not isolated from Logic Output). Dielectric strength – 500V d.c. for 1 minute.


### 5.4.5 Digital Input

Type: Volt-free

Minimum Pulse: 250ms




## ...5 INSTALLATION




**Note 1.** The Analog Output and Logic Output use a common positive terminal that is capable of driving both outputs simultaneously.

**Note 2.** Fit arc suppression components if switching inductive loads.



**Fig. 5.5 Electrical Connections**



# CUSTOMER CONFIGURATION LOG

LEU5

CnFG

AbCd

----

EFGH

----

JPLn

----

PrSt

----

LEU6

CnFG

ENGH

100.0

----

ENGL

0.0

----

rt.H1

100.0

----

rt.L0

0.0

----

SP-H

100.0

----

SP-L

0.0

----

SP-1

10.0

----

SP-2

20.0

----

SP-3

30.0

----

SP-4

40.0

----

OP1H

100

----

OP2H

100

----

C-OP

0

----

R.PAS

0

----

S.PAS

0

----

Addr

1


----

-----

Company Standard settings are shown in the lower display

# CUSTOMER SETUP LOG



----- 

<div>LEU.1 dSPL</div>		<div>LEU.2 tUNE</div>	<div>LEU.3 SEtP</div>	<div>LEU.4 PrFL</div>
		<div>Str 1 100.0</div>		
	<div>rYc 1 5.0</div>	<div>LSPt 125.8</div>		<div>End 1 200.0</div>
<div>Code 0</div>	<div>cYc 2 5.0</div>	<div>rSPn 145.8</div>		<div>rEt 1 10.0</div>
	<div>HYS t 0.1</div>	<div>R 1hP 800.0</div>		<div>SPt 2 60.0</div>
	<div>Pb-h 100.0</div>	<div>R 2hP 200.0</div>		<div>End 3 100.0</div>
	<div>Pb-c 100.0</div>	<div>rRt 0 1000</div>		<div>rEt 3 20.0</div>
<div>Rt nE OFF</div>	<div>Intr 30</div>	<div>b 1AS 0.0</div>		<div>SPt 4 30.0</div>
	<div>rSEt 50.0</div>	<div>r rEt OFF</div>		<div>SSSP YES</div>
	<div>dr 1U. 1.0</div>	<div>ORdJ 0.3</div>		<div>PHYS YES</div>
	<div>OLAP 0.0</div>			<div>rPt 5 0</div>

-----

Company Standard settings are shown in the lower display

Instrument Serial Number: \_\_\_\_\_

Product Code: C 1 0 0 / \_ \_ \_ \_ / \_ \_ \_ \_

# Customer Support

ABB Instrumentation provides a comprehensive after sales service via a Worldwide Service Organization. Contact one of the following offices for details on your nearest Service and Repair Centre.

## United Kingdom

ABB Instrumentation Limited

Tel: +44 (0)1480 475321

Fax: +44 (0)1480 470787

## United States of America

ABB Automation Inc.

Instrumentation Division

Tel: +1 215-674-6000

Fax: +1 215-674-7183

## Italy

ABB Kent-Taylor SpA

Tel: +39 (0) 344 58111

Fax: +39 (0) 344 58278

### Client Warranty

Prior to installation, the equipment referred to in this manual must be stored in a clean, dry environment, in accordance with the Company's published specification. Periodic checks must be made on the equipment's condition.

In the event of a failure under warranty, the following documentation must be provided as substantiation:

1. A listing evidencing process operation and alarm logs at time of failure.
2. Copies of operating and maintenance records relating to the alleged faulty unit.

# ABB



W H Good (Instrumentation) Ltd  
·PROCESS INSTRUMENTATION & CALIBRATION ·  
Carrs Industrial Estate, Haslingden, Rossendale, Lancs. BB4 5JT  
Telephone: (01706) 211416 - 4 Lines, 215586, 217060 Fax: (01706) 831540  
e-mail:instruments@whgood.co.uk